

# ASSEMBLY AND INSTALLATION INSTRUCTIONS

CP-CFU150

**WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.**

**NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements.  
2. READ AND SAVE THESE INSTRUCTIONS.**

1. Please turn off the power at fuse or circuit box before starting on the installation.
2. Thread two headless screws through the mounting plate, then secure them with four lock nuts (Two on each side of the mounting plate). Adjust the length of the headless screws if necessary.
3. Attach the mounting plate to the outlet box by using two mounting screws.
4. Pull out the outlet wires and the house grounding wire from the outlet box. Make wire connections using the wire nuts:
  - The black wire from the fixture to the black wire from the power source.
  - The white wire from the fixture to the white wire from power source.
  - Attach the fixture grounding wire to the mounting plate with the green grounding screw. Then connect it to the house grounding wire with a wire nut.Carefully tuck the wires back into the outlet box.
5. Attach the canopy to the mounting plate by inserting the headless screws, then secure it with the bolt nuts.
6. Install bulbs (not included). See relamping label at socket area or packaging for maximum allowed wattage.
7. Attach the glass shade to the cap by inserting the nipple, then secure them with a rubber pad, metal pad and hex nut. Attach the cover to the glass shade by inserting the nipple and secure it with the finial.
8. Turn on the power at the main fuse or circuit breaker box.

